

buttons and meaning

zoom 2-sec	on- or off- camera	
on camera		
mode	switch between iTTL / M / Multi	
iTTL	auto-setting for: power / HSS / FEC / FEB / FEV / rear / DOF	
	ch/grp	(zoom setting down) *4
	zoom	zoom setting up *4
	left/right	exposure compensation +/-
M	manual	
	ch/grp	(zoom setting down) *4
	zoom	zoom setting up *4
	left/right	brightness +/-
	up/down	brightness +/- small steps
Multi	manual, multiframe	
	ch/grp	(zoom setting down) *4
	zoom	zoom setting up *4
	left/right	brightness +/-
	up/down	na
	OK	change times/frequency(Hz) set with left/right

off camera (zoom 2sec)

mode	switch between Sc(ETTL)/Sn(iTTL)/S1(M)/S2(M)	
Sc/Sn	TTL (= auto) canon/nikon	
	ch/grp	change channel/group
	left/right	ch/grp up down set by OK
S1	manual slave, triggered by first flash master do not use preflash / red-eye on master ! see 'on camera' M mode	
S2	manual slave, triggered by 2nd flash master can be used for preflash / red-eye on master ! see 'on camera' M mode	

general info

*1	max shutter speed	1/8000
*2	exposure compensation range	- 5 EV -> + 5 EV
*3	brightness range	1/128 -> 1/1 (full)
*4	zoom-instelling	als de plastic zoom-filter op de flits uitgeklaapt wordt, komt deze automatisch op zoom 14, en kan niet aangepast via zoom-button